

PARTS LIST FOR MODEL P-76

| Item No. | Part No. | Part Name | No. Req. |
|----------|-----------|---------------------------|----------|
| 1 | P16.05 | Base | 1 |
| 2 | S1.52-1 | Pump Cup Spreader | 1 |
| 3 | S1.53 | Pump Cup | 4 |
| 4 | P16.55 | Pump Cup Retaining Nut | 1 |
| 5 | P16.75 | Pump Packing | 2 |
| 6 | P16.54 | Pump Plunger Packing Nut | 1 |
| 7 | P16.51 | Pump Plunger | 1 |
| 8 | J.16 | Valve Ball | 1 |
| 9 | S1.16 | Valve Ball | 1 |
| 10 | S1.183 | Outlet Valve Spring | 1 |
| 11 | S1.167B | Valve Plug Gasket | 2 |
| 12 | CB9.185 | Valve Plug | 1 |
| 13 | P16.18 | Oil Strainer Screen | 1 |
| 14 | 1.03 | Drive Screw | 4 |
| 15 | 1.74 | Release Valve Packing | 3 |
| 16 | MJ11-1 | Release Valve Packing Nut | 1 |
| 17 | P16.10 | Release Valve Spindle | 1 |
| 18 | P13.240-1 | Release Valve Wheel | 1 |
| 19 | P13.12 | Release Valve Wheel Pin | 1 |
| 20 | P16.25 | Reservoir | 1 |
| 21 | P75.266-1 | Reservoir Cap | 1 |

| Item No. | Part No. | Part Name | No. Req. |
|--|--|------------------------|----------|
| 22 | P76.267-1 | Pump Rest | 1 |
| 23 | P75.181 | Pump Rest Lock Nut | 1 |
| 24 | MJ23 | Filler Plug Gauge | 1 |
| 25 | P75.22 | Filler Plug | 1 |
| 26 | P76.60 | Beam | 1 |
| 27 | P76.57 | Pump Plunger Cross Pin | 1 |
| 28 | P76.63 | Beam Pin | 1 |
| 29 | S1.58 | Beam Pin Cotter | 2 |
| 30 | P75.70 | Pump Handle | 1 |
| 31 | P60.308 | Pump Handle Knob | 1 |
| 32 | 1.26E | Name Plate | 1 |
| Blackhawk Hydraulic Oil #30 43 Cu. In. (about 1 1/2 Pint) | | | |
| SUB-ASSEMBLIES | | | |
| P16.05A | Base (Items 1, 8, 9, 10, 11, 12, 13, 14) | | |
| P16.05B | Base (Items 1 to 19) | | |
| P16.10A | Release Valve (Items 17, 18, 19) | | |
| P75.70A | Handle (Items 30, 31) | | |



